

KABLOSUZ KAPI ZİLİ - WIRELESS DOORBELL / CT-103

Kablosuz kapı zili'nin kurulumu çok kolaydır ve iç dekorasyonunuzda kablo kirliliğini ortadan kaldırmaktadır. Kumandasının uzak mesafelerde bile etkili bir şekilde çalışması (100m) sayesinde bir çok farklı mekanlarda kullanabilirsiniz. CATA uzaktan kumandalı kapı zilleri farklı frekanslara sahip olduğu için aynı mekanda birden fazla CATA uzaktan kumandalı kapı zili kullanabilirsiniz. 36 farklı melodiye sahiptir. (Up Music Down butonu ile ayarlayabilirsiniz.) Ses tonu seviyesini "Volume" butonu ile ayarlayabilirsiniz. Alkalın pil 1 yıl dayanabilir. (20 defa / gün) Algılama mesafesi açık alanlarda 100 metre kapalı alanlarda 30-50 metre aralığındadır. Yüksek müzikal sesi ile iç mekanlarda algılaması mesafesi hesaplanarak istenilen yere yerleştirilebilir. Çevre dostu ve Enerji tüketimi azdır.

The wireless doorbell is very easy to install and removes the wire bit in interior decoration. You can use it in many different places the effective operation of the remote at long distances (100m). CATA remote control doorbells have different frequencies .In this way, you can use more than one CATA remote control doorbell in the venue It has 36 different melodies. (You can adjust it with the Up Music Down button.) You can adjust the tone with the "Volume" button. Alkaline battery can last 1 year. (20 times / day) The detection distance is within 100 meters of the outdoor area , it is within 30-50 meters of indoor area. It can be placed desired by calculating the sensing distance indoors with loud musical sound. (Environmentally friendly and energy consumption is low.)

KULLANMA TALİMATI


Basma düğmesini kapıya vida, yapıştırıcı veya çift taraflı bant ile sabitleyiniz. Yağmura maruz bırakılmadığından ve metal objelerin yakınına konmadığından emin olunuz. Pil haznesinin kapağını açınız ve 2 adet AA boyutundaki alkalın pili yerleştiriniz. Ürün pili garanti kapsamında değildir. Pilin akmasından kaynaklı sorunlar garanti kapsamında değildir. Kapı zili, iç mekanlarda algılama mesafesi hesaplanarak istenilen yere yerleştirilebilir ve yeri istenilen şekilde değiştirilebilir. Belli bir zaman sonra düzenli çalışmayan zilin pillerinin değiştirilmesi gerekmektedir.

OPERATING INSTRUCTION


The push switch secure to the door with a screw, adhesive or double-sided tape. Make sure that the product is not exposed to rain and placed near metal objects. Open the battery compartment door and insert 2 AA size alkaline batteries. The product battery is not covered by the warrant.Problems caused by battery runny are not covered under warranty. The doorbell can be placed desired by calculating the detection distance indoors and the product place can be changed as desired) When the bell that does not work regularly after a certain period of time needs replacing the batteries

Montaj Diyagramı Assembly Diagram

1. Alıcı Montajı 1. Receiver Assembly



Alıcı
Receiver




Pili takın ve kapağı yerine yerleştirin.
Insert the battery and replace the cover.

2. Verici Montajı 2. Transmitter Assembly



Verici
Transmitter



Kapağı açın.
Open the cover.

Pili takın ve kapağı kapatın
Insert the battery and close the cover

CT-103